



Premium Laptop Cleaning Kit

## Step 3 • Screen cleaning

Take the screen cleaning fluid and screen cleaner from case. • Use provided cleaning fluid, spray on screen at 15 cm distance; 1-2 sprays are enough to clean the whole screen. • Immediately use the screen cleaner to wipe clean the screen. To clean all corners of the screen, use the triangular ends of the cleaner.

### Step 4 • General surface cleaning


The enclosed microfibre cloth will provide surface cleaning for other parts of the laptop, such as the rest of the keyboard area, or the top casing of the laptop. Simply wipe over the area that requires cleaning, to make the laptop as clean as ever!

### Step 5 • Finishing the cleaning process

After finishing the cleaning process, be sure to place all the tools back in the case for next time use. We recommend the user to clean the laptop at least once a week to maintain optimal performance.







# **Product Information**

① Keyboard cleaning pen ② Ultra-fine microfibre cloth ③ Screen cleaner ④ Blower ⑤ Surface cleaning fluid ⑥ Cleaning pen tips ⑦ Screen cleaning fluid

## **General Information**

### **Specifications**

- Dimension: L242.5mm X W124.5mm X D40mm
- Weight: 338 g

#### **Accessories**

- Keyboard cleaning pen (1 pcs) and extra cleaning pen tip (2 pcs)
- · Screen cleaner (1 pcs)
- · Ultra-fine microfibre cloth
- Screen cleaning fluid (30cc. bottle)
- Surface cleaning fluid (10cc. bottle)
- Blower (1 pcs)

#### Caution

- Refrain from exerting excessive force on the screen during cleaning, as this may cause damage to the screen.
- Refrain from using too much cleaning fluid for either screen or keyboard cleaning as this may cause dripping.
- Do not point the spray at human eyes. Consult doctor immediately in case of eye contact with the spray.
- Do not point the triangular ends of the flat screen cleaner directly at any screen as this may cause damage to the screen.
- · Keep out of reach of children.

# Instruction

## Step 1 • Dust blowing

Take out the blower from the case . Locate the dusting area, direct the nozzle towards it and start blowing by pressing the blower. You may adjust the blowing angle for better performance.

## Step 2 • Keyboard cleaning

Take surface cleaning fluid and cleaning pen from the case. Ensure that there is a cleaning tip on the pen. ① Drip 1-2 drops of cleaning fluid onto the tip and start cleaning the keyboard. ② The angle of the cleaning tip can be adjusted to achieve the desired cleaning performance. Cleaning the keyboard spacing would require to hold the pen in a steep angle for optimal performance, whereas for keyboard surface the pen will require a more flat angle in relation to the keyboard. Clean the keyboard in horizontal tracks first, followed by vertical tracks.

Air vents, or other hard to reach areas, can also be cleaned by using the pen. The tip is washable, but it is advised that it is replaced regularly for optimal performance.

